

OUTDOOR BATTERY BOX



BOD-DX

*Outdoor Battery Box 16" High, 25" Deep, 25" Wide, (Mounting Tray 2" H X 17"D X 17"W) **Painted Cream***

BOD-DD

*Outdoor Battery Box 16" High, 34" Deep, 25" Wide, (Mounting Tray 2" H X 26"D X 17"W) **Painted Cream***

BOD-DDX

*Outdoor Battery Box 16" High, 42" Deep, 25" Wide, (Mounting Tray 2" H X 34"D X 17"W) **Painted Cream***

